


Tripmeter

Shows mileage per trip.

There are two tripmeters, tripmeter A (2) and tripmeter B (3). Switch between the A and B displays by pressing the SEL button (4) repeatedly.

To reset the tripmeter, push and hold the RESET button (5) with the display in the tripmeter A or tripmeter B mode.



- (1) Tripmeter
- (2) Tripmeter A
- (3) Tripmeter B
- (4) SEL button
- (5) RESET button