


Front Turn Signal Bulb


1. Remove the screw (1).
2. Remove the cover (2) from the rearview mirror (3) carefully in the procedure shown in the illustration.



- (1) Screw
(2) Cover

(3) Rearview mirror

3. Turn the socket (4) counterclockwise, and remove it.
4. Slightly press the bulb (5) and turn it counterclockwise.
5. Install a new bulb in the reverse order of removal.
 - Use only the amber bulb.



- (4) Socket
(5) Bulb