

Odometer


Shows accumulated mileage.

Tripmeter

Shows mileage per trip.

There are two tripmeters, tripmeter A (3) and tripmeter B (4). Switch between the A and B displays by pressing the MODE button (5) repeatedly.

To reset the tripmeter, push and hold the MODE button (5) with the display in the tripmeter A or tripmeter B mode.



(1) Odometer

(2) Tripmeter

(3) Tripmeter A

(4) Tripmeter B

(5) MODE button