

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [ NOTE (1) ]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
			MONTH	6	12	18	24	30	36		
DRIVE CHAIN			EVERY 1,000 km (600 mi) I, L								97-102
DRIVE CHAIN SLIDER					I		I		I	103	
BRAKE FLUID		NOTE (3)		I	I	R	I	I	R	26-28	
BRAKE PAD WEAR				I	I	I	I	I	I	114	
BRAKE SYSTEM			I		I		I		I	26-28, 116	
* BRAKE LIGHT SWITCH					I		I		I	122	
* HEADLIGHT AIM					I		I		I	-	
CLUTCH SYSTEM					I		I		I	29	
CLUTCH FLUID		NOTE (3)		I	I	R	I	I	R	29	
SIDE STAND					I		I		I	105	
* SUSPENSION					I		I		I	104	
* NUTS, BOLTS, FASTENERS			I		I		I		I	-	
** WHEELS/TYRES					I		I		I	-	
** STEERING HEAD BEARINGS			I		I		I		I	-	