

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [ NOTE (1) ]									REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36		
			× 1,000 mi	0.6	4	8	12	16	20	24		
			MONTH		6	12	18	24	30	36		
				EVERY 1,000 km (600 mi) L, L								97-102
					I			I		I		103
		NOTE (3)			I	I	R	I	I	R		26-28
					I	I	I	I	I	I		114
				I		I		I		I		26-28, 116
*						I		I		I		121
*						I		I		I		62
						I		I		I		29
		NOTE (3)			I	I	R	I	I	R		29
						I		I		I		105
*						I		I		I		104
*				I		I		I		I		-
**						I		I		I		-
**				I		I		I		I		-