

SPARK PLUGS

(Refer to the maintenance precautions on page 66).

Recommended plugs:

CR9EHVX-9 (NGK)

This motorcycle uses the spark plugs that have a platinum coated center electrode. Be sure to observe the following when servicing the spark plugs.

- Do not use wire brush to clean the electrodes. If the electrode is contaminated with accumulated objects or dirt, clean the electrode using a “plug cleaner”.

Consult your authorized Honda dealer for this service.

- Use only “wire-type feeler gauge” to check the spark plug gap to prevent damaging the platinum coating of the center electrodes. Never use “leaf-type feeler gauge”.
- Do not adjust the spark plug gap. If the gap is out of specification, replace the spark plug with a new one.

1. Remove the lower cowl (page 42).
2. Remove the upper cowl cover (page 44) and inner panel (page 45).