


Speed and Mileage Unit Change (E type only)

The speedometer displays both “km/h” and “mph”.

The odometer/tripmeter displays both “km” and “mile”.

Push and hold the select button (6) to select “km/h”/“km” or “mph”/“mile”.



(6) Select button