OPERATION

page			
	MOTORCYCLE SAFETY		
1	IMPORTANT SAFETY		
	INFORMATION		
2	PROTECTIVE APPAREL		
4	LOAD LIMITS AND GUIDELINES		
R	PARTS LOCATION		
_			
11	INSTRUMENTS AND		
	INDICATORS		
28	MAJOR COMPONENTS		
28	MAJOR COMPONENTS (Information you need to operate		
28			
28 28	(Information you need to operate this motorcycle)		
	(Information you need to operate this motorcycle) SUSPENSION		
28 29	(Information you need to operate this motorcycle) SUSPENSION		
28 29 32	(Information you need to operate this motorcycle) SUSPENSION BRAKES		
28 29 32	(Information you need to operate this motorcycle) SUSPENSION BRAKES CLUTCH COOLANT		
28 29 32 34	(Information you need to operate this motorcycle) SUSPENSION BRAKES CLUTCH COOLANT FUEL		
28 29 32 34 36	(Information you need to operate this motorcycle) SUSPENSION BRAKES CLUTCH COOLANT FUEL		

oage			
46	ESSENTIAL II	NDIVIDUAL	
	COMPONENTS		
46	IGNITION SWI	TCH	
47	KEYS		
49	IMMOBILIZER	SYSTEM (HISS)	
51	RIGHT HANDI	EBAR CONTRÓL	
53	LEFT HANDLE	EBAR CONTROLS	