

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
			MONTH								
* FUEL LINE						I		I		I	—
* THROTTLE OPERATION						I		I		I	94
* AIR CLEANER		NOTE (2)					R			R	—
SPARK PLUGS				EVERY 12,000 km (8,000 mi) I, EVERY 24,000 km (16,000 mi) R							89
* VALVE CLEARANCE								I			—
ENGINE OIL			R		R			R		R	83
ENGINE OIL FILTER			R		R			R		R	86
* ENGINE IDLE SPEED			I	I	I	I	I	I	I	I	95
RADIATOR COOLANT		NOTE (3)			I			I		R	34
* COOLING SYSTEM					I			I		I	—
* SECONDARY AIR SUPPLY SYSTEM						I		I		I	—