

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH		6	12	18	24	30	36		
	DRIVE CHAIN		I, L EVERY 1,000km (600mi)								97
	DRIVE CHAIN SLIDER				I			I		I	103
	BRAKE FLUID	NOTE (3)		I	I	R	I	I	R		29
	BRAKE PAD WEAR			I	I	I	I	I	I		112
	BRAKE SYSTEM		I		I		I		I		29, 112
*	BRAKE LIGHT SWITCH				I		I		I		—
*	HEADLIGHT AIM				I		I		I		—
	CLUTCH SYSTEM		I	I	I	I	I	I	I		32
	SIDE STAND				I		I		I		105
*	SUSPENSION				I		I		I		104
*	NUTS, BOLTS, FASTENERS		I		I		I		I		—
**	WHEELS/TYRES				I		I		I		—
**	STEERING HEAD BEARINGS		I		I		I		I		—