



4. Turn the socket (5) 90° counterclockwise, then pull it out toward you.
5. Slightly press down on the bulb and turn it counterclockwise.
6. Install a new bulb in the reverse order of removal.

NOTE:

- * Do not use bulbs other than that specified.
- * After installing a new bulb, check that the light operates properly.



(5) Socket

(6) Bulb