

<b>(Ref.No.) Description</b>	<b>Function</b>
(12) RESET button	<p><b>Except E type:</b> This button is used to reset the tripmeter or to adjust the time.</p> <p><b>For E type:</b> This button is used to reset the tripmeter or to adjust the time or to change the speed and mileage units for the speedometer/odometer/tripmeter.</p>
(13) ADJ button	This button is used to select the tripmeter or to adjust the time.