

# Cargo Compartments


## Front Hook

The front hook ( 1 ) may be used to hang a small shopping bag. Do not carry more than the maximum weight limit.

**maximum weight limit:** 3 lbs (1.5 kg)

Do not attach a large bag or other item that can interfere with the movement of your feet.

## BELOW HANDLEBAR



(1) front hook