

Fuel

Never use stale or contaminated gasoline or an oil/gasoline mixture. Avoid getting dirt, dust, or water in the fuel tank.


Fuel Capacity

Fuel tank capacity, including reserve:
1.32 US gal (5.0 l)

Refueling Procedure

Refer to *Safety Precautions* on page 70.

UNDER STEPBOARD



- (1) tab (3) ignition key
(2) fuel tank lid (4) fuel fill cap

1. Pull the tab (1) and open the fuel tank lid (2).
2. Insert the ignition key (3) in the fuel fill cap (4) and turn it clockwise.