


Engine Oil & Strainer Screen


Drain the Engine Oil:

1. Park the scooter on its center stand on a firm, level surface.
2. If the engine is cold, start it and let it idle for 3–5 minutes. Turn the engine off. Wait 2–3 minutes for the oil to settle.
3. Place a drain pan under the engine oil drain bolt (2).
4. To drain the oil, remove the oil filler cap/dipstick (1), engine oil drain bolt (2), and sealing washer (3).

RIGHT SIDE



LEFT SIDE



- (1) oil filler cap/dipstick
- (2) engine oil drain bolt
- (3) sealing washer