

## If Your Engine Quits or Won't Start

---

<b>SYMPTOM: Starter motor doesn't operate.</b>	
<b>POSSIBLE CAUSE</b>	<b>WHAT TO DO</b>
ignition switch OFF	Turn the ignition switch ON.
engine stop switch OFF	Turn the engine stop switch to RUN.
blown fuse	Replace with a new fuse of the same rating (page 158).
battery lead loose	Tighten the battery lead.
low (or dead) battery	Charge the battery (page 129). If charging doesn't help, see your Honda dealer.
faulty starter motor	If all possible causes are negative, the starter motor may be faulty. See your Honda dealer.