

## OPERATION

### PRE-RIDE INSPECTION

For your safety, it is very important to take a few moments before each ride to walk around your motorcycle and check its condition. If you detect any problem, be sure you take care of it, or have it corrected by your Honda dealer.

#### **▲WARNING**

Improperly maintaining this motorcycle or failing to correct a problem before riding can cause a crash in which you can be seriously hurt or killed.

Always perform a pre-ride inspection before every ride and correct any problems.

1. Engine oil level – add engine oil if required (page 22). Check for leaks.
2. Fuel level – fill fuel tank when necessary (page 18). Check for leaks.
3. Front and rear brakes – check operation; make sure there is no brake fluid leakage. Adjust free play if necessary (pages 12 – 15).
4. Tyres – check condition and pressure (pages 23 – 27).
5. Spokes and rim locks – check and tighten if necessary (page 72).
6. Drive chain – check condition and slack (page 66). Adjust and lubricate if necessary.
7. Chain slider – check slider wear (page 67).
8. Throttle – check for smooth opening and full closing in all steering positions. Adjust free play if necessary (pages 63 – 64).