

ITEMS	FREQUENCY	WHICHEVER → COMES FIRST ↓	INITIAL MAINT.	REGULAR MAINT. INTERVAL					REFER TO PAGE
			km	150	1,000	2,000	3,000	4,000	
			mi	100	600	1,200	1,800	2,400	
	NOTE	MONTH	1	6	12	18	24		
	DRIVE CHAIN	NOTE (1)	I, L	Every 500 km (300 mi) or every 3 months: I,L					66
	DRIVE CHAIN SLIDER			I	I	I	I	67	
	BRAKE FLUID	NOTE (2)		I	I	I	I	12	
	BRAKE SHOE/PAD WEAR			I	I	I	I	77, 78	
	BRAKE SYSTEM		I	I	I	I	I	12, 77, 78	
	CLUTCH SYSTEM		I	I	I	I	I	16	
	SIDE STAND				I		I	81	
*	SUSPENSION				I		I	79, 80	
*	SPARK ARRESTER			Every 1,600 km (1,000 mi) or every 100 operating hours: C					65
*	NUTS, BOLTS, FASTENERS		I		I		I	-	
**	WHEELS/TYRES		I	I	I	I	I	23, 72	
**	STEERING HEAD BEARINGS		I		I		I	-	