

REMOVAL FROM STORAGE

1. Uncover and clean the motorcycle.
2. Change the engine oil if more than 4 months have passed since the start of storage.
3. Charge the battery as required.
Install the battery.
4. Fill the fuel tank with fresh petrol.
5. Perform all Pre-ride Inspection checks (page 35).
6. Test ride the motorcycle at low speeds in a safe riding area away from traffic.