


## TOOL KIT

The tool kit (1) is in the tool kit compartment (2) behind the left side cover.

To open the tool kit compartment, insert the ignition key (3) and turn it counterclockwise to unlock. To close the tool kit compartment, close the compartment cover (4) and turn the ignition key clockwise to lock.

Some roadside repairs, minor adjustments and parts replacement can be performed with the tools contained in the kit.

- Spark plug wrench
- 17 mm Box end wrench
- 24 mm Box end wrench
- 8 × 12 mm Open end wrench
- 10 × 14 mm Open end wrench
- Pliers
- No. 2 Phillips screwdriver
- Screwdriver handle
- No. 2 screwdriver
- Extension bar
- 5 mm Hex wrench
- 6 mm Hex wrench
- Tool bag



- (1) Tool kit
- (2) Tool kit compartment
- (3) Ignition key
- (4) Compartment cover