

# Contents

<b>MOTORCYCLE SAFETY.....1</b>	<i>Service Procedures</i>	Tire Selection for Track Conditions.....145
Important Safety Information.....2	<i>Fluids &amp; Filters</i>	Personal Fit Adjustments .....146
Important Safety Precautions.....2	<i>Fuel System.....41</i>	<b>TIPS.....147</b>
Loading.....3	<i>Engine Oil.....43</i>	Transporting Your Motorcycle.....148
Accessories & Modifications.....4	<i>Transmission Oil.....46</i>	Storing Your Honda.....149
Safety Labels.....5	<i>Coolant.....48</i>	You & the Environment.....151
<b>OPERATING CONTROLS.....7</b>	<i>Air Cleaner.....51</i>	Troubleshooting.....152
Operation Component Locations.....8	<i>Crankcase Breather.....53</i>	<b>TAKING CARE OF THE UNEXPECTED...153</b>
<b>BEFORE RIDING.....9</b>	<i>Engine</i>	If a Fuse Blows.....154
Are You Ready to Ride?.....10	<i>Throttle.....54</i>	If Your Battery Is Low (or Dead).....155
Is Your Motorcycle Ready to Ride?.....11	<i>Clutch System.....56</i>	<b>TECHNICAL INFORMATION.....157</b>
Pre-ride Inspection.....11	<i>Hot Start Lever.....60</i>	Vehicle Identification.....158
<b>BASIC OPERATING INSTRUCTIONS.....13</b>	<i>Spark Plug.....61</i>	Specifications.....159
Safe Riding Precautions.....14	<i>Exhaust Pipe/Muffler.....62</i>	Torque Specifications.....160
Starting & Stopping the Engine.....15	<i>Spark Arrester.....65</i>	Emission Control Systems.....164
Preparation.....15	<i>Valve Clearance.....66</i>	Oxygenated Fuels.....166
Fuel Valve.....15	<i>Piston/Piston Rings/Piston Pin.....76</i>	Competition Logbook.....167
Starting Procedure.....15	<i>Chassis</i>	Optional Parts List.....169
Flooded Engine.....16	<i>Suspension.....84</i>	Spare Parts & Equipment.....170
How to Stop the Engine.....16	<i>Brakes.....88</i>	Wiring Diagram.....171
Shifting Gears.....17	<i>Wheels.....92</i>	<b>CONSUMER INFORMATION.....173</b>
Braking.....18	<i>Tires &amp; Tubes.....93</i>	Authorized Manuals.....174
Parking.....19	<i>Side Stand.....95</i>	Warranty Coverage.....175
Post-ride Inspection.....20	<i>Drive Chain.....96</i>	Warranty Service.....176
Break-in Guidelines.....21	<i>Steering Damper.....99</i>	Contacting Honda.....177
<b>SERVICING YOUR HONDA.....23</b>	<i>Additional Maintenance Procedures.....102</i>	Your Honda Dealer.....178
<i>Before You Service Your Honda</i>	<i>Electrical</i>	The Honda Rider's Club (USA only).....179
The Importance of Maintenance.....24	<i>Battery.....104</i>	<b>TABLE OF CONTENTS.....180</b>
Maintenance Safety.....25	<i>Headlight &amp; Taillight.....106</i>	<b>INDEX.....182</b>
Important Safety Precautions.....25	<i>Appearance Care.....108</i>	<b>QUICK REFERENCE</b>
Maintenance Schedule.....26	<b>ADJUSTMENTS FOR COMPETITION...111</b>	
General Competition Maintenance.....29	Front Suspension Adjustments.....112	
Before & After Competition Maintenance.....33	Rear Suspension Adjustments.....126	
Between Motos & Practice Maintenance...33	Suspension Adjustments for Track	
After Competition Maintenance.....33	Conditions.....130	
<i>Service Preparations</i>	Suspension Adjustment Guidelines.....131	
Maintenance Component Locations.....35	Carburetor Adjustment & Tuning Tips.....134	
Seat.....36	Steering Damper Adjustment.....141	
Fuel Tank.....37	Chassis Adjustments.....143	
Subframe Upright Position.....39	Gearing.....144	