

# Starting & Stopping the Engine

---

## Flooded Engine

If the engine fails to start after repeated attempts, it may be flooded with excess fuel. To clear a flooded engine:

1. Turn the engine stop switch to OFF ( ⓧ ).
2. Push the choke lever down all the way to OFF.
3. Open the throttle fully.
4. Crank the engine several times with the kickstarter.
5. Turn the engine stop switch to RUN ( ○ ).
6. Follow the *High Air Temperature* starting procedure (page 32 ).

## How to Stop the Engine

To stop the engine, shift into neutral, turn the engine stop switch to OFF ( ⓧ ).