

## **PARKING BRAKE (UY type)**

The front brake lever has a lock which allows it to be used as a parking brake.

Always set the parking brake when parking and before starting the engine.

### **NOTE:**



- \* Using the parking brake in freezing weather may cause the brakes to freeze in the locked position.

### To set the parking brake:

Squeeze the front brake lever (1) and lock it with the lock lever (2).

### To unlock the parking brake:

Squeeze the front brake lever until the lock lever releases.



(1) Front brake lever      (2) Lock lever