


## Steering Lock (Optional part)

The motorcycle has a steering lock (1) on the steering column under the headlight case. To lock the steering, turn the handlebar all the way to the steering stop, either to the right or left, insert the key in the lock, turn the key 60° to the left, and press the lock all the way in. Turn the key back to the original position and remove. To unlock the steering, perform the locking sequence in the reverse order.



## Bloqueador del Manubrio (Unidades opcionales)

La motocicleta está provista de un bloqueador del manubrio (1) en la columna de dirección debajo de la caja de faro. Para bloquear el manubrio, gire el manubrio completamente a la izquierda o a la derecha hasta el fin de curso, inserte la llave en el bloqueador, gírela 60° a la izquierda y empújela completamente. Gire la llave otra vez a la posición original para retirarla.