


Oil change and oil filter cleaning:

Drain the oil while the engine is still warm.

1. Remove the oil filler cap.
2. Place an empty oil drain pan under the engine and then remove the drain plug (1).
3. Operate the kick starter several times to aid in complete draining of the remaining oil.
4. Remove the kick starter pedal and foot rest from the engine.
5. Remove the right crankcase cover by unscrewing the screws.



O 000034

Cambio de aceite y limpieza del filtro de aceite:

Drene el aceite mientras que el motor esté todavía caliente.

1. Quite la tapa de llenado de aceite.
2. Coloque un recipiente de aceite debajo del motor, luego, quite el tapón de drenaje (1).
3. Haga jugar el kickstarter varias veces para acelerar la purga del aceite restante.
4. Desmonte el pedal del kickstarter y el descansapié del motor.
5. Desmonte la cubierta del cárter derecho destornillando los tornillos.