

Reset to factory default setting

The set value can be returned to initial setting.

- 1 Select “DEFAULT ALL” menu on the main menu screen, and then the display moves to the menu screen of “DEFAULT ALL”.

→P.28

- 2 Press the **SELECT** button to select either “NO” (not reset) or “YES” (reset).



③ When selecting “YES”

Press the **SET** button, the set value will return to initial setting, and then the display returns to the main menu screen.

When selecting “NO”

Press the **SET** button, the set value maintained, and then the display returns to the main menu screen.

Initial values

- Backlight brightness setting [BRIGHTNESS]: Level 3
- HISS Indicator setting [HISS]: ON
- Clock [CLOCK]: maintained (not applicable)
- Speed and mileage unit [DIST]:
 - Except E type km
 - E type mile
- Fuel mileage meter unit [FUEL]:
 - Except E type l/100km
 - E type mile/gal