

Maintenance

Please read “Importance of Maintenance” and “Maintenance Fundamentals” carefully before attempting any maintenance. Refer to “Specifications” for service data.

Importance of Maintenance	P. 71	Clip B.....	P. 94
Maintenance Schedule	P. 72	Battery.....	P. 95
Maintenance Fundamentals	P. 75	Spark Plugs	P. 96
Tool kit	P. 85	Engine Oil	P. 98
Removing & Installing Body Components ..	P. 86	Coolant	P. 102
Seat.....	P. 86	Brakes	P. 104
Left Inner Panel	P. 87	Clutch	P. 107
Over Head Cover	P. 88	Side Stand	P. 108
Left Side Cover	P. 89	Final Drive Oil	P. 109
Saddlebag	P. 90	Throttle	P. 110
Left Fairing Pocket	P. 91	Other Adjustments	P. 111
Left Shroud	P. 92	Brake Lever	P. 111
Left Middle Cowl.....	P. 93	Rear Suspension.....	P. 112
Clip A.....	P. 94	Headlight Aim.....	P. 113