

## Inspecting the Brake Pads

Check the condition of the brake pad wear indicators.

The pads need to be replaced if a brake pad is worn to the indicator.

- 1. Front** Inspect the brake pads from below of the brake caliper.
  - Always inspect both left and right brake calipers.

- 2. Rear** Inspect the brake pads from the rear left of the motorcycle.
  - If necessary have the pads replaced by your dealer.
  - Always replace both left and right brake pads at the same time.

