

Maintenance

Please read “Importance of Maintenance” and “Maintenance Fundamentals” carefully before attempting any maintenance. Refer to “Specifications” for service data.

Importance of Maintenance	P. 48	Coolant	P. 76
Maintenance Schedule	P. 49	Brakes	P. 78
Maintenance Fundamentals	P. 52	Side Stand	P. 81
Tool kit	P. 63	Drive Chain	P. 82
Removing & Installing Body Components ..	P. 64	Clutch	P. 87
Seat	P. 64	Throttle	P. 90
Right Under Cowl Lid.....	P. 65	Crankcase Breather	P. 91
Centre Lower Cowl.....	P. 66	Other Adjustments	P. 92
Right Under Cowl	P. 67	Headlight Aim	P. 92
Clip.....	P. 68	Brake Light Switch.....	P. 93
Battery.....	P. 69		
Engine Oil	P. 70		