


## Battery Care

Inspecting and topping up the electrolyte level should be performed frequently as indicated in the Maintenance Schedule (page 159) and Pre-riding Inspection (page 84). The electrolyte level must be maintained between upper (2) and lower (3) level marks. If low, add distilled water to raise the level. Use a syringe or plastic funnel. The battery is accessible by removing the left side cover.

NOTE: The side cover (1) will be damaged if pulled roughly toward you, move it from (A) to (B) as shown in the figure.



## Mantenimiento de la batería

La inspección del nivel de electrolito de la batería y, eventualmente, el relleno del mismo deberán efectuarse tan frecuentemente como se indica en el Programa de Mantenimiento (pág. 159), y en la sección Inspección antes de puesta en marcha (pág. 84). El nivel del electrolito deberá estar entre la marca superior (2) y la interior (3) del nivel. Si el nivel esté más bajo que lo indicado arriba, agregue el agua destilada. Utilice una jeringa o embudo de plástico. La batería es accesible desmontando la cubierta lateral izquierda.

NOTA: Ya que la cubierta lateral (1) puede dañarse si se tira de ella violentamente hacia Vd., moverla de (A) a (B) como se muestra en la figura.

