

BREAK-IN PROCEDURE

During the first 1,000 km (600 miles) operate your new motorcycle so the engine neither pulls laboriously nor exceeds 80% of the lower Red Zone rpm limit in any gear. Avoid full throttle operation, and select your gear changes to spare the engine undue stress. Careful break-in operation during the initial mileage period will measurably extend the service life of the engine.

RODAJE

Durante los primeros 1.000 km, conduzca su nueva motocicleta de tal manera que el motor no tire excesivamente ni exceda el 80% del límite de rpm de la zona roja inferior. Evite usarla a velocidades extremas y use el cambio de velocidades para evitar esfuerzos innecesarios del motor. La operación cuidadosa de rodaje en los primeros kilómetros prolongará considerablemente la vida útil del motor.