


## Storage Compartment

The storage compartment (1) is in the rear cowl. This compartment is for storage of this owner's manual, other documents and the tool bag. Insert the ignition key into the lock and turn it clockwise to unlock the compartment.

When washing your motorcycle, be careful not to flood this area with water.

**WARNING** The storage compartment is for light weight items. Do not carry more than 2 kg (4.4 lbs) of cargo, including the tool bag and other documents.



## Compartimiento para el almacenamiento

El compartimiento para el almacenamiento (1) se encuentra en la cubierta posterior del motor. Este compartimiento se utiliza para guardar el manual del propietario y otros documentos y la bolsa de herramientas. Introduzca la llave de encendido en el cierre y gíela hacia la derecha para abrir el compartimiento.

Cuando lave su motocicleta tenga cuidado de no inundar este lugar de agua.

**ADVERTENCIA:** El compartimiento de almacenamiento es para objetos ligeros.

No llevar en este compartimiento una mayor de 2 kg (4,4 lbs), incluyendo la bolsa de herramientas y otras documentos.