

CONTENTS

SERIAL NUMBER LOCATION	5
CONTROL LOCATIONS	6
OPERATING INSTRUCTIONS	10
Instruments.....	10
Warning and Indicator Lights.....	12
Ignition Switch.....	15
Engine Stop Switch.....	16
Starter Button.....	16
Headlight Dimmer Switch.....	17
Horn Button.....	17
Turn Signal Switch.....	17
Steering Lock.....	18
Helmet Holder.....	19
Top and Side Compartments.....	19
Battery Cover.....	20
Rear Shock Absorbers.....	20
Kick Starter Pedal.....	21
FUEL AND OIL	22
Fuel Valve.....	22
Fuel Filler Cap.....	23
Engine Oil Recommendation.....	24