


SERIAL NUMBER LOCATION


The frame serial number ① is stamped on the right side of the steering head. The engine serial number ② is stamped on top of the right side of the crankcase. These serial numbers are required when

registering the motorcycle.

Refer to frame and engine serial numbers when ordering replacement parts to ensure that you will obtain the correct parts for your model series.



① Frame serial number



② Engine serial number