

Loading

The combined weight of the rider, passenger, luggage and additional accessories must not exceed 500 kg (1102 lbs), Zul Ges Gewicht. Luggage weight alone should not exceed 20 kg (44 lbs).

1. Keep luggage and accessory weight low and close to the center of the motorcycle. Load weight equally on both sides to minimize imbalance. As weight is located farther from the motorcycle's center of gravity, handling is proportionally affected.
2. Adjust tire pressure (TIRES, page 26), front fork air pressure and rear shockabsorber air pressure (SUSPENSION, page 38) to suit load weight and riding conditions.

Carga

El peso combinado del conductor, del pasajero, de la carga y de los accesorios adicionales no tiene que exceder de 500 kg (1102 lbs), Zul Ges Gewicht. El peso de la carga por sí sola no deberá exceder de 20 kg (44 lbs).

1. Mantener el peso de la carga y de los accesorios bajo y cerca del centro de la motocicleta. El peso de carga por igual en ambos lados para reducir desequilibrios. A medida que el peso se coloca apartado del centro de gravedad de la motocicleta, la conducción queda proporcionalmente afectada.
2. Ajustar la presión de los neumáticos (NEUMATICOS, página 26), de la horquilla frontal y del amortiguador trasero (SUSPENSION, página 38) para adaptar el peso de la carga y las condiciones de conducción.