


EQUIPMENT AND CONTROLS

Control Location



- (1) Compartment lock
- (2) Fuse box and ACC terminal
- (3) Horn button
- (4) Turn signal switch
- (5) Passing light switch
- (6) Headlight dimmer switch
- (7) Clutch lever

- (8) Choke knob
- (9) Speedometer
- (10) Coolant temperature gauge
- (11) Warning and indicator lights
- (12) Fuel gauge
- (13) Tachometer
- (14) Front brake fluid reservoir

- (15) Front brake lever
- (16) Engine stop switch
- (17) Throttle grip
- (18) Headlight switch
- (19) Starter button
- (20) Ignition switch
- (21) Coolant reserve tank cap