

SADDLEBAGS (GL1500CT only)

The saddlebags (1) are for light weight items.

Cargo in each saddlebags should not exceed:


9.0 kg (20.0 lbs)

To open the saddlebags:

Insert the ignition key (2) into the lid lock (3) and turn it counterclockwise.

To lock the saddlebags, close the lid and turn the ignition key clockwise.

Make sure the lids are locked.



(1) Saddlebag

(3) Lid lock

(2) Ignition key