



- 
- Using a special tool and a torque wrench, install the new oil filter and tighten to a torque of:

26 N·m (2.7 kgf·m , 19 lbf·ft)

Use only the Honda Genuine oil filter or a filter of equivalent quality specified for your model. Using the wrong Honda filter or a non-Honda filter which is not of equivalent quality may cause engine damage.

- Install a new sealing washer onto the drain bolt.

Install the drain bolt and tighten.

Oil drain bolt torque:

34 N·m (3.5 kgf·m , 25 lbf·ft)

- Fill the crankcase with the recommended grade oil; approximately:

3.7 ℓ (3.9 US qt , 3.3 Imp qt)

- Install the oil fill cap/dipstick.

- Start the engine and let it idle for 3–5 minutes.

- 2–3 minutes after stopping the engine, check that the oil level is at the upper level mark on the oil fill cap/dipstick with the motorcycle upright on firm, level ground. Make sure there are no oil leaks.

- Install the right engine side cover (page 139).

- Install the front lower cover (page 141).

