


Indicators

Your Honda MUV's instrument panel has a number of indicators to keep you informed and alert you to possible problems. Each is described in the following pages.



Neutral Indicator

This indicator comes on and stays on when the transmission is in neutral.

Reverse Indicator

This indicator comes on and stays on when the transmission is in reverse.

Parking Brake Indicator

This indicator comes on and stays on when the parking brake is on.