


PARTS FUNCTION

Instruments and Indicators

The indicators and warning lights are grouped between the instruments, above the headlight. Their functions are described in the tables on the following pages.



- (1) Speedometer
- (2) Odometer
- (3) Left turn signal indicator
- (4) Oil level warning light
- (5) Right turn signal indicator
- (6) Tachometer
- (7) Tachometer red zone
- (8) High beam indicator
- (9) Neutral indicator
- (10) Coolant temperature gauge
- (11) Tripmeter
- (12) Tripmeter reset button

