


3. Check for correct synchronization of the oil pump (5) under the crankcase. Check the reference mark (6) aligns with the index mark (7) with the throttle fully opened. See your authorized Honda dealer if any misalignment occurs.

CAUTION:

* *Failure to perform oil pump synchronization may result in serious engine damage.*

(A) Open

(B) Closed



(5) Oil pump

(7) Index mark

(6) Reference mark