
SERIAL NUMBER

The frame and engine serial numbers are required when registering your scooter. They may also be required by your dealer when ordering spare parts. Record the numbers here for your reference.

FRAME NO.



(1) Frame no.

The frame number (1) is stamped on the right side of the frame body.

The engine number (2) is stamped on the left side of the crank case near the rear wheel.

ENGINE NO. _____



(2) Engine no.