## **Crankcase Breather**

Service more frequently when riding in rain, at full throttle, or after the scooter is washed or overturned. Service if the deposit level can be seen in the transparent section of the drain tube.

If the drain tube overflows, the air filter may become contaminated with engine oil causing poor engine performance. ▶ P. 72

## **Recommended Coolant**

Pro Honda HP coolant is a pre-mixed solution of antifreeze and distilled water.

## Concentration:

50% antifreeze and 50% distilled water

A concentration of antifreeze below 40% will not provide proper corrosion and cold temperature protection. A concentration of up to 60% will provide better protection in colder climates.

## NOTICE

Using coolant not specified for aluminum engines or using ordinary tap water can cause corrosion.