

To open the fuel fill cap (4), rotate the fuel fill cap counterclockwise until it stops. Lift off the fuel fill cap.

Do not overfill the tank. There should be no fuel in the filler neck (5).

After refueling, be sure to tighten the fuel fill cap firmly by turning it clockwise.


Make sure that the arrow marks (6) on the fuel fill cap and fuel tank are aligned.

Close the fuel tank lid.

⚠ WARNING

Petrol is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks, and flame away.
- Refuel only outdoors.
- Wipe up spills immediately.



- (4) Fuel fill cap
(5) Filler neck

(6) Arrow marks