


When the battery is low:

When the battery is low, the Honda smart card key indicator (1) flashes 5 times when you turn the ignition switch ON.

See page 73 for the battery replacement.

When the battery of the Honda smart card key is dead, see page 68 for instructions to unlock the ignition switch.



(1) Honda smart card key indicator

Honda Smart Card Key has operating problems:

The Honda smart card key indicator flashes if you lose the card key while riding, if the battery is low, or if strong radio waves or noise are affecting the system. However, this does not affect the operation of your scooter.

Turning the ignition switch OFF while the Honda smart card key indicator is flashing, locks the ignition switch.

If you do not have the card key, the ignition switch can be unlocked by using the mechanical key and the ID tag. See page 68 .