


## **Mode Shift Switch (NSS250EX)**

To shift between the automatic shift mode and 6-speed manual mode, press the mode shift switch (3).



(3) Mode shift switch