

5. Tyres—check condition and pressure (pages 47 – 52 ).
6. Throttle—check for smooth opening and full closing in all steering positions.
7. Lights and horn—check that headlight, stop/tail light, turn signals, indicators and horn function properly.
8. Engine stop switch—check for proper function (page 77 ).
9. Side stand ignition cut-off system—check for proper function (page 157 ).