

(Ref. No.) Description	Function
(1) Fuel gauge	Shows approximate fuel supply available (see page 15).
(2) Speedometer	Shows Riding speed.
(3) Odometer	Shows accumulated mileage.
(4) Tachometer	Shows engine rpm.
(5) Anti-lock brake system indicator (ABS) (NSS250A)	This light normally comes on when the ignition is turned ON, and goes off after you ride the scooter at speed above 10 km/h. If there is a problem with the Anti-lock Brake System, this light comes on and remains on (see page 20).