

Installation Notes:

- Make sure that the lug (8) on the fork leg is contacting the lug on the speedometer gear box. Tighten the axle bolt and axle pinch bolts to specified torques.

Axle bolt torque:

59 N·m (6.0 kgf·m , 43 lbf·ft)


Axle pinch bolts torque:

22 N·m (2.2 kgf·m , 16 lbf·ft)

- Fit the caliper over the disc, taking care not to damage the brake pads. Install the caliper fixing bolts and tighten to a torque of:
30 N·m (3.1 kgf·m , 22 lbf·ft)
- Connect the speedometer cable with the set screw.
- After installing the wheel, apply the brake several times and then check if the wheel rotates freely. Recheck the wheel if the brake drags or if the wheel does not rotate freely.

▲WARNING

- * If a torque wrench was not used for installation, see your authorized Honda dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capacity.



(8) Lugs