

MAINTENANCE SCHEDULE

The following items require some mechanical knowledge. Certain items (particularly those marked * and * *) may require more technical information and tools. Consult your authorized Honda Dealer.

Perform the Pre-ride Inspection (page 32) at each scheduled maintenance period.

I: INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY

C: CLEAN R: REPLACE A: ADJUST L: LUBRICATE

ITEMS	FREQUENCY	WHICHEVER COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to pages
			→	1	6	12	18	24	30	36	
			x 1.000 km x 1.000 mi	0.6	4	8	12	16	20	24	
		MONTHS	6	12	18	24	30	36			
* FUEL LINE					I		I		I	—	
* FUEL STRAINER SCREEN				C	C	C	C	C	C	—	
* THROTTLE OPERATION					I		I		I	56-57	
* CARBURETOR CHOKE					I		I		I	—	
AIR CLEANER	NOTE (2)						R		R	46	
CRANKCASE BREATHER	NOTE (3)			C	C	C	C	C	C	—	
SPARK PLUG				I	R	I	R	I	R	54-55	
* VALVE CLEARANCE			I	I	I	I	I	I	I	—	
ENGINE OIL			R	EVERY 3,000 km (2,000 mi) R						R	47-51
ENGINE OIL FILTER			R		R		R		R	52-53	
* ENGINE OIL STRAINER SCREEN IN DOWN TUBE					C		C		C	—	
* CARBURETOR IDLE SPEED			I	I	I	I	I	I	I	58	
* SECONDARY AIR SUPPLY SYSTEM	NOTE (4)				I		I		I	—	